CABINET PARTS

REFRIGERATOR

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2306981	Use & Care Guide
	2223996	Installation Instructions
	2223419	Service & Wiring Sheet
	2308412	Energy Guide
	628370	Modular Icemaker Service Sheet
2		Front Roller Asm
	2306950	Left Side
	2306951	Right Side
3	2223263	Strap, Roller
4	2306949	Roller, Rear (2)
5	2223388	Clip, Retainer (4)
6	2155013	Clip, Grille
7	489478	Screw
8	2223545	Shim
9		Hinge Top, RC
	2307008W	White
	2307008T	Biscuit
	2307008B	Black
10	3400113	Screw
11	3400243	Screw
12	2223520	Hinge Assembly, Bottom−RC
13		Filler, Wrapper
	2223893W	White
	2223893T	Biscuit
	2223893B	Black
14		Grille
	2223514W	White
	2223514T	Biscuit
	2223514B	Black
15	3400108	Screw
16		Hinge, Top FC
	2307007W	White
	2307007T	Biscuit
	2307007B	Black
17	489464	Screw
18	940139	Drain Fitting
19	2199954	Tube, Extension
20	1108439	Clip, Drain Tube
21	2223409	Cover, Unit
22	2223387	Pin, Roller (4)
23	549193	Clamp, Service Cord
24	489084	Screw
25	2223460	Hinge Assembly, Bottom−FC
26		Button, Water Filter
	2260503W	White
	2260503T	Biscuit
	2260503B	Black
27	2260526	Housing, Water Filter
28	4396710	Water Filter
29	2223751	Door Closer, FC
30		Cap, Water Filter
	2260518W	White
	2260518T	Biscuit
	2260518B	Black
31		Cabinet (Not A Serviceable Part)
32	489483	Screw
35	3400858	Screw
36	2224020	Tube, Filter Outlet
37	2305536	Tube, Filter Inlet

REFRIGERATOR LINER PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2223338	Escutcheon, Meat Pan Control
3	2223339	Slide Meat Pan Control
4	2179404K	Wine Rack
6	1118894	Switch, Rocker Arm
7	2188820	Thermistor
9	2206273	Ladder, Shelf (2)
10	2261601	Housing, Door Control
11	489084	Screw
14	2171846	Release Valve
15	2209204	Clip, Thermistor
17	1116793	Cover, Thermistor
18	489478	Screw
19	2304597	Gasket, Air Baffle
20	2223403	Cover, Air Baffle
24	2224076	Air Diffuser Assembly
25	2220377	Air Baffle
29	2162085	Socket
31	2223876	Reservoir
32	2307062	Strap
33	2255743	Light Bulb
34	2223663	Light Lens
37	488280	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2223288	Pan Assembly (Includes #31)
2	2223309	Button, Humidity
3	2223308	Slide, Humidity
5	2223525	Cover, Meat Pan (Includes Items 13, 14, 15 & 20)
6	2223261	Snack Pan
7	2216624K	Egg Bin
9	2223307	Cover, Crisper (Includes 2 & 3)
10	2223591	Glass, Cover
13	2174478	Eyelet, Roller
14	2188212	Roller
15	489211	Screw
16	2223235	Crisper Pan
17	2223526	Meat Pan (Includes 13, 14, 19 & 22)
18	2224059	Shelf and Frame Assembly (3)
19	489261	Screw
20	2223487	Deflector
22	2203029	Handle
25	2196485	Stud Assembly
27	3400894	Screw
28	2196483	Stud Assembly
29	8281158	Screw
31	2223320	Slide, Pan

FREEZER LINER PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	2223777	Spacer, Slide (2)
3	3400893	Screw
5	2196483	Stud Assembly
6	2223690	Basket, Deep (2)
8	8281158	Screw
9	2223500	Shelf Assembly, Cantilever (2)
11	2223782	Front, Basket
13		Shelf Track
	2223787	Right Side
	2223788	Left Side
14	2223681	Shelf, Fixed
15	2223692	Basket, Lower
16	486298	Screw
17	842534	Clip, Air Duct (2)
18		Glide Assembly, Basket (2)
	2301544	Right Side
	2301545	Left Side
19	2223991	Cover, Emitter
20	8534064	Screw
22	2198635	Spring
23	2198634	Pin
24	2198665	Tube, P.C. Board
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2223321	Cover, Ice Maker
28		Slide, Ice Maker Mounting
	2212321	Right Side
	2306900	Left Side
29	489478	Screw
30	489214	Screw
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255558	Cover, Receiver
37	2255562	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
45		Ladder
	2198609	Left Side
	2198610	Right Side
46	2306901	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2223317	Ice Bin
2	2255574	Crusher Bin
3	2258222	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (6)
6	2255460	Cover, Crusher
7	2257022	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257024	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
19	2255575	Button, Bin
20	2212371	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw
23	8281163	Screw
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	999536	Drive Shaft
31	2256154	Enclosure, Motor
32	2188860	Dispenser, Motor
33	2212305	Cover
36	2212365	Sleeve, Coupling
37	2187725	Wire Harness, IDI Motor

REFRIGERATOR DOOR PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #7)
	2223835W	White
	2223835T	Biscuit
	2223835B	Black
	2224132S	Stainless Steel
2	2203087K	Trim, Shelf
3	2255421	Dairy Door
4	2223463K	Door Bin
5	2223464K	Mat, Bin (3)
6	2255411	Clip, Mounting
7		Door Gasket, Magnetic
	2223841	Mist Beige
	2223911	Black
8		Handle (Includes #9)
	2305993W	White
	2305993T	Biscuit
	2305993B	Black
9	8533920	Screw
10	2223879	Dairy Compartment
11	489491	Screw
12	2182178	Door Closer, Upper Cam
13	2308091	Thimble, Top
14	489420	Screw
15		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black
16	2223239K	Door Bin (2)
17	3400012	Screw
18	2224173	Door Bin, Shallow
20	2156006K	Plug, Trim
21	2220214	Nameplate

FREEZER DOOR PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2223842W	White
	2223842T	Biscuit
	2223842B	Black
	2224191SB	Stainless Steel
2		Handle (Includes #6)
	2305993W	White
	2305993T	Biscuit
	2305993B	Black
3	2255411	Clip, Mounting
4	489491	Screw
5	3400012	Screw
6	8533920	Screw
7	2171157K	Shelf Bin
8		Door Gasket, Magnetic
	2223850	Mist Beige
	2223912	Black
9	2223334	Trivet, Tilt−Out (2)
10	2219982	Trim, Door Shelf
11	2308091	Thimble, Top
12	2304309	Basket, Tilt−Out (2)
13	2255459K	Bottle, Ice Pack
14	2223752	Door Closer, Upper Cam
16	489420	Screw
17		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black

DISPENSER FRONT PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2304355	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206670W	White
	2206670T	Biscuit
	2206670B	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2255431W	White
	2255431T	Biscuit
	2255431B	Black
12	2180224	Guide, Ice
13	2305571	Gasket
15	2306937	Bracket, Control
17		Lever, Water Dispenser
	2255432W	White
	2255432T	Biscuit
	2255432B	Black
19		Overlay, Front Cover (Not Available, Order #23)
20		LED Display (Not Available, Order #23)
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 13, 19, 20 & 21)
	2224183W	White
	2224183T	Biscuit
	2224183B	Black
24	2188355	Bracket, Dispenser
25	2195051	Strain Relief
26	3400065	Screw
27	2252127	Sleeve, Mechanism

AIR FLOW PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2223733	Retainer, Fan Motor
3	2223298	Air Scoop
4	2223303	Air Duct, Upper
5	2223771	Air Duct Freezer
6	2188824	Bi−Metal, Defrost
7	2259385	Fan Motor
8	2169142	Fan Blade
10	2223986	Fan Grommet (2)
12	2310110	Harness, Fan Evaporator (Includes #6)
13	2155789	Gasket Cover
16	2203876	Gasket
17	2223413	Cover, Evaporator
18	8281159	Screw (6)
21	489478	Screw
22	2223395	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)





Illus. No.	Part No.	DESCRIPTION
1	2306990	Control Box (Includes #6)
2	2223877	Latch
3	2306952	Trim, Control Box
4	2223512	Spring, Torsion
5	2223882	Heat Shield Asm
6	2307037	Control Board Asm
10	2223506	Light Lens, Control Box
17	2223857	Light Socket
19	2223678	Light Bulb

UNIT PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	777070	Screw
2	2225834	Fan, Blade
3	2223315	Condenser Assembly
4	8281197	Screw
5	3400524	Screw (6)
6	2223703	Housing, Control Board
7	2223351	Tube Suction
8	2161302	Sleeve
10	2301979	Plate, Mounting
11	8281196	Screw
12	2215676	Cover, Terminal
14	2185788	Clamp, Cable
15	488649	Screw
18	2223353	Tube, Condenser to Heat Loop
19	2307028	Electronic Control
20	2306932	Baseplate
21	489478	Screw
22	2188823	Evaporator
23	2161324	Clamp
24	2188729	Fan, Motor
25	2223398	Tray, Evaporator

Illus. No.	Part No.	DESCRIPTION
26	2224022	Heat Shield
27	2199167	Drier
28	2223801	Compressor (Includes Items 12 & 39)
29	2223800	Spacer (5)
31	2187849	Harness, Main Control
32	2224024	Fan, Motor Bracket
33	2210737	Heater, Defrost
34	2304287	Clip
36	2304098	Inverter Box
37	489473	Screw
38	2223352	Tube, Discharge
39		Grommet (4)
	2183042	Production
	4387558	Service
41	2223394	Extension, Air Baffle
42	2155547	Clip, Heat Shield
45	2187737	Unit Harness
63	2209709	Connector, Water Tube

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

6.00 oz.
(R−134A)

ICEMAKER PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting, Water Tube
5	628379	Clip, Fuse
9	489478	Screw
10	2315533	Water Valve Asm
14	2208136	Tube Clip
18	2174358	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	627843	Ejector
24	2198598	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
32	2187467	Harness, Wiring
33	2212322	Bracket, Icemaker Mounting
35	626678	Module Assembly (Includes Items 37 & 38)
37	626676	Motor
38	489136	Screw
100	2198597	Icemaker Assembly

OPTIONAL PARTS

For Models: GC3SHEXNQ02, GC3SHEXNT02, GC3SHEXNB02, GC3SHEXNS02
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*350956	Enamel, Almond (12 Oz. Spray Can)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72107	Brush Touch−Up Kit (Almond)
	72032	Brush Touch−up kit (Black)
	4392899	Brush Touch−Up Kit (Biscuit)

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	2258249	Ice Container Assembly

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)
	4392900	Enamel, Biscuit (1 Qt. Uncut)

TORX SCREW WRENCH

	1117510	Torx Key